




SWISHER

228002 - Cleaner Furniture Polish Aerosol

Cleans and protects wood furniture, metal, leather, chrome, stainless steel and vinyl surfaces. Citrus scent.



Long Description

Benefits

Product Specifications

Storage & Usage

Do not breathe dust/ fume/ gas/ mist/ vapors/ spray. Use only with adequate ventilation. Contents under pressure. Do not puncture. Wash hands thoroughly after handling. In case of mechanical malfunction, or if in contact with unknown dilution of product, wear full Personal Protective Equipment (PPE). Keep in a cool, well-ventilated place. Keep out of reach of children. Keep container tightly closed. Store in suitable labeled containers.

Brand	Manufacturer	Product Category
SWISHER	PROGUARD / SWISHER	

MFG #	SPC #	GTIN	Pack	Pack Desc.
6101312	228002	10025469037425	6	6/17 OZ

Gross Weight	Net Weight	Country of Origin	Kosher	Child Nutrition
6.79lb	5.78lb	USA	No	No

Shipping Information						
Length	Width	Height	Volume	TlxHl	Shelf Life	Storage Temp From/To
8.34in	5.72in	9.86in	0.27ft3	37x4	0DAYS	40°F / 111°F



SWISHER

228002 - Cleaner Furniture Polish Aerosol

Cleans and protects wood furniture, metal, leather, chrome, stainless steel and vinyl surfaces. Citrus scent.



Additional Images

